

E² Elite Engineering's Rocker-Panel Guards Installation on a C5 & C6 Corvette



Before



After

Summary

Congratulations and thank you for your purchase! Below you will find detailed instructions on how to correctly install and permanently attach your set of **Rocker-Panel Guards**. Unlike our Aluminum Frame Rails, these hard plastic rails are designed to be used with Jacking Pads as shown in the “After” picture.

Keep in mind the “Red” Rocker-Panel Guards shown in the pictures are for view clarity only, your set of Guards will be black in color.

If you have any questions during the install, don't hesitate to give us a call.

Recommended Tools:

- Elite Engineering's **Rocker-Panel Guards (right and left hand)** and hardware.
- Electric Hand Drill
- Center Punch or nail and hammer
- Pilot Drill bit, approx. 1/8" diameter
- Loctite
- Philips Screwdriver



Be sure your car is safely and securely lifted before attempting this installation.
The use of jack stands and/or Rhino Ramps is highly recommended.

Underside of vehicle shown:



Take note of the Passenger's Side (Labeled "P") and Driver's Side (Labeled "D") Rocker-Panel Guards

They are not identical. There is a right and left hand Rocker-Panel Guard.



First, Hand Fit your Rocker-Guards into position:

It's best to use Two Jacking Pads (shown here in blue) to accurately position the Rocker-Panel Guard into it's exact location.



Remove backing from double sided tape:

Double Sided tape is used as an aid to temporarily hold the Rocker-Panel Guards into position until the mounting screws are installed.



Mounting Rails:

Once the Double-Sided tape is exposed, hand position Rocker-Panel Guards into their final location. Using a Hand Punch, Nail, or Pencil, mark each of the (4) screw locations.



Drilling Holes:

The (8) Stainless Steel screws that are included with your Rocker-Panel Guards are self-tapping screws. However, to ease installation, it is recommended to drill a small pilot hole (approximately 1/8" diameter) for each screw installed.



Securing Rocker-Panel Guards:

Using a hand drill or screw driver, install the 8 Stainless Steel screws (4 per Guard). You can also add a drop or two of Loctite to each screw thread to prevent the possibility of them loosening. Your installation is now complete!!!

